


Tooth Notation:


The Zsigmondy-Palmer system is the preferred system of tooth notation in the UK (eg UR1, UL3) over the FDI system (eg 11, 23).

Zsigmondy-Palmer Notation




FDI (Two digit charting system)

In this system the quadrant symbol is replaced by a number. The quadrant number is the first digit while the second number identifies the individual tooth.




Conventional Dental Charting Symbols


It is helpful to use a chart which separate existing restorations from those that are required. This chart is available in printable format in resources.




**ACCEPTED NOTATIONS
Incisor Teeth**



**ACCEPTED NOTATIONS
Premolar and Molar Teeth**



**ACCEPTED NOTATIONS
Premolar and Molar Teeth**



Periodontal charting:

A full periodontal charting should include the following;

1. 6 point pocket depth measurements (ideally with sites > 5mm highlighted)
2. Bleeding on probing (at each site indicated as a red dot above the pocket depth measure)
3. Recession
4. Furcation involvement and grade (Grade I, II, III, IV)
5. Mobility score (I, II, III)